

DMX CHANNELS / DMX KANALEN / DMX-KANÄLE / CANALES DMX / CANAUX DMX / KANAŁY DMX

6 Channels

Channel	Function	Value	Description
1	Colour	000-255	Red 0-100%
2		000-255	Green 0-100%
3		000-255	Blue 0-100%
4		000-255	White 0-100%
5	Chase and Sound	000-007	No Function
		008-022	Colour Effect 1
		023-037	Colour Effect 2
		038-052	Colour Effect 3
		053-067	Colour Effect 4
		068-082	Colour Effect 5
		083-097	Colour Effect 6
		098-112	Colour Effect 7
		113-127	Colour Effect 8
		128-142	Colour Effect 9
		143-157	Colour Effect 10
		158-172	Colour Effect 11
		173-187	Colour Effect 12
		188-202	Colour Effect 13
		203-217	Colour Effect 14
		218-232	Colour Effect 15
233-247	Colour Effect 16		
248-255	Sound Effect 1-16		
6	Speed	000-255	Chase speed from slow to fast

9 Channels

Channel	Function	Value	Description
1	Dimming	000-255	All dimming
2	Strobe	000-255	Strobe
3	Colour	000-255	Red 0-100%
4		000-255	Green 0-100%
5		000-255	Blue 0-100%
6		000-255	White 0-100%
7	Auto	000-255	Auto program
8	Chase and Sound	000-007	No Function
		008-022	Colour Effect 1
		023-037	Colour Effect 2
		038-052	Colour Effect 3
		053-067	Colour Effect 4
		068-082	Colour Effect 5
		083-097	Colour Effect 6
		098-112	Colour Effect 7
		113-127	Colour Effect 8
		128-142	Colour Effect 9
		143-157	Colour Effect 10
		158-172	Colour Effect 11
		173-187	Colour Effect 12
		188-202	Colour Effect 13
		203-217	Colour Effect 14
		218-232	Colour Effect 15
233-247	Colour Effect 16		
248-255	Sound Effect 1-16		
9	Speed	000-255	Chase speed from slow to fast

16 Channels

Channel	Function	Value	Description
1	Dimming	000-255	All dimming 1
2	Strobe	000-255	Strobe 1
3	Colour 1	000-255	Red 0-100%
4		000-255	Green 0-100%
5		000-255	Blue 0-100%
6		000-255	White 0-100%
7	Auto	000-255	Auto program 2
8	Dimming	000-255	All dimming 2
9	Strobe	000-255	Strobe 2
10	Colour 2	000-255	Red 0-100%
11		000-255	Green 0-100%
12		000-255	Blue 0-100%
13		000-255	White 0-100%
14	Auto	000-255	Auto program 3
15	Chase and Sound	000-007	No Function
		008-022	Colour Effect 1
		023-037	Colour Effect 2
		038-052	Colour Effect 3
		053-067	Colour Effect 4
		068-082	Colour Effect 5
		083-097	Colour Effect 6
		098-112	Colour Effect 7
		113-127	Colour Effect 8
		128-142	Colour Effect 9
		143-157	Colour Effect 10
		158-172	Colour Effect 11
		173-187	Colour Effect 12
		188-202	Colour Effect 13
		203-217	Colour Effect 14
		218-232	Colour Effect 15
233-247	Colour Effect 16		
248-255	Sound Effect 1-16		
16	Speed	000-255	Chase speed from slow to fast

30 Channels

Channel	Function	Value	Description
1	Dimming	000-255	All dimming 1
2	Strobe	000-255	Strobe 1
3	Colour 1	000-255	Red 0-100%
4		000-255	Green 0-100%
5		000-255	Blue 0-100%
6		000-255	White 0-100%
7	Auto	000-255	Auto program 1
8	Dimming	000-255	All dimming 2
9	Strobe	000-255	Strobe 2
10	Colour 2	000-255	Red 0-100%
11		000-255	Green 0-100%
12		000-255	Blue 0-100%
13		000-255	White 0-100%
14	Auto	000-255	Auto program 2
15	Dimming	000-255	All dimming 3
16	Strobe	000-255	Strobe 3
17	Colour 3	000-255	Red 0-100%
18		000-255	Green 0-100%
19		000-255	Blue 0-100%
20		000-255	White 0-100%
21	Auto	000-255	Auto program 3
22	Dimming	000-255	All dimming 4
23	Strobe	000-255	Strobe 4
24	Colour 4	000-255	Red 0-100%
25		000-255	Green 0-100%
26		000-255	Blue 0-100%
27		000-255	White 0-100%

Channel	Function	Value	Description
28	Auto	000-255	Auto program 4
29	Chase and Sound	000-007	No Function
		008-022	Colour Effect 1
		023-037	Colour Effect 2
		038-052	Colour Effect 3
		053-067	Colour Effect 4
		068-082	Colour Effect 5
		083-097	Colour Effect 6
		098-112	Colour Effect 7
		113-127	Colour Effect 8
		128-142	Colour Effect 9
		143-157	Colour Effect 10
		158-172	Colour Effect 11
		173-187	Colour Effect 12
		188-202	Colour Effect 13
		203-217	Colour Effect 14
218-232	Colour Effect 15		
233-247	Colour Effect 16		
248-255	Sound Effect 1-16		
30	Speed	000-255	Chase speed from slow to fast

58 Channels

Channel	Function	Value	Description
1	Dimming	000-255	All dimming 1
2	Strobe	000-255	Strobe 1
3	Colour 1	000-255	Red 0-100%
4		000-255	Green 0-100%
5		000-255	Blue 0-100%
6		000-255	White 0-100%
7	Auto	000-255	Auto program 1
8	Dimming	000-255	All dimming 2
9	Strobe	000-255	Strobe 2
10	Colour 2	000-255	Red 0-100%
11		000-255	Green 0-100%
12		000-255	Blue 0-100%
13		000-255	White 0-100%
14	Auto	000-255	Auto program 2
15	Dimming	000-255	All dimming 3
16	Strobe	000-255	Strobe 3
17	Colour 3	000-255	Red 0-100%
18		000-255	Green 0-100%
19		000-255	Blue 0-100%
20		000-255	White 0-100%
21	Auto	000-255	Auto program 3
22	Dimming	000-255	All dimming 4
23	Strobe	000-255	Strobe 4
24	Colour 4	000-255	Red 0-100%
25		000-255	Green 0-100%
26		000-255	Blue 0-100%
27		000-255	White 0-100%
28	Auto	000-255	Auto program 4
29	Dimming	000-255	All dimming 5
30	Strobe	000-255	Strobe 5
31	Colour 5	000-255	Red 0-100%
32		000-255	Green 0-100%
33		000-255	Blue 0-100%
34		000-255	White 0-100%
35	Auto	000-255	Auto program 5
36	Dimming	000-255	All dimming 6
37	Strobe	000-255	Strobe 6
38	Colour 6	000-255	Red 0-100%
39		000-255	Green 0-100%
40		000-255	Blue 0-100%
41		000-255	White 0-100%
42	Auto	000-255	Auto program 6

Channel	Function	Value	Description
43	Dimming	000-255	All dimming 7
44	Strobe	000-255	Strobe 7
45	Colour 7	000-255	Red 0-100%
46		000-255	Green 0-100%
47		000-255	Blue 0-100%
48		000-255	White 0-100%
49	Auto	000-255	Auto program 7
50	Dimming	000-255	All dimming 8
51	Strobe	000-255	Strobe 8
52	Colour 8	000-255	Red 0-100%
53		000-255	Green 0-100%
54		000-255	Blue 0-100%
55		000-255	White 0-100%
56	Auto	000-255	Auto program 8
57	Chase and Sound	000-007	No Function
		008-022	Colour Effect 1
		023-037	Colour Effect 2
		038-052	Colour Effect 3
		053-067	Colour Effect 4
		068-082	Colour Effect 5
		083-097	Colour Effect 6
		098-112	Colour Effect 7
		113-127	Colour Effect 8
		128-142	Colour Effect 9
		143-157	Colour Effect 10
		158-172	Colour Effect 11
		173-187	Colour Effect 12
		188-202	Colour Effect 13
203-217	Colour Effect 14		
218-232	Colour Effect 15		
233-247	Colour Effect 16		
248-255	Sound Effect 1-16		
58	Speed	000-255	Chase speed from slow to fast

MENU / MENÜ / MENÚ

Mode	Program	Value	Description
DMX MODE	ADDR	001-512	DMX address
Channels	CHND	6 CH	Channel select
		9 CH	
		16 CH	
		30 Ch	
		58 CH	
Master/Slave	SLND	Mast	Master/ slave mode
		SL 1	
		SL2	
Sound	SOUN	So 0 – So 16	Sound sensivity adjust
		Se 99 – Se 0	Auto effect choose
Auto	AUTO	Au 0 – Au 16	Auto mode select
		SP 0 – SP 9	Auto speed
Static colours	COLO	Red	Red 0 – 100%
		Green	Green 0 – 100%
		Blue	Blue 0 - 100%
		White	White 0 -100%
Display	DISP	Dsip	Display invert
Version	UER	U....	Software version